

Maynard Trap opening and closing

Trap Rules:

1. Safety first
2. Action open at all times unless its your turn to shoot
3. Point barrel in safe direction
4. Only load 1 shell at a time
5. Only load when standing on the line
6. Target loads only #7.5, 8 or 9 shot, no 3" shells

Opening Procedure:

1. Retrieve mics and junction box from trailer (combo 6102) and set them up at each station.



2. Place orange cone on top of house when inside
3. Open both doors completely and use barrel bolts to hold in place



4. CHECK TO MAKE SURE THROWING ARM IS NOT COCKED
 - a. If it is cocked release target before stepping in front of machine



Throwing arm is highlighted in yellow. It is in released position so it is safe

5. Run cord out from house and plug into junction box 3 pin connector



6. Plug master controller cord into junction box 4 pin connector



Plug cords from mics into junction box 2 pin connectors

7. Turn on light switch at back of house



8. Turn on hydraulic pump. If temperature is below 30 degrees wait 15 minutes to warm up fluid
9. Standing to the side of the house turn on machine. Machine should start to rotate and the arm should cock.



Turn on master controller switch. The red LED should turn on. Master switch automatically turns off after 2 minutes if not launching targets

Shoot


Closing Instructions:

1. When done shooting stand to the side of house and press machine toggle switch all the way down to release target and shut off machine. THIS IS IMPORTANT FOR SAFETY AND LONGEVITY OF SPRING
2. Shut off pump and turn off light switch at back of house
3. Roll up cord and store on door hook. MAKE SURE CORD DOES NOT GET KINKED OR PINCHED



4. Shut off pump and light switch

5. Fill machine with targets Sign in and Pay \$4 per round \$5 per round for guests





6. Secure doors and lock them